

Underground Primary Pad and Service Layout

Scale: NTS

Date: 7/21/09



Notes

- 1) Have SVEC spot Locations
- 2) Call TN One Call (1-800-351-1111)
- 3) Dig or Trench ditch to noted depth
Note: If less than the noted depth contact SVEC
- 4) Sch 80 PVC Required when under any Roads or Driveways
- 5) SVEC only allows 2 elbows in ditch, 1 at the House and 1 at the Pole
- 6) Install conduit
- 7) Install 1/4" Nylon Pull Rope in Conduit
- 8) Install Concrete Pad to SVEC Spec.
- 9) Contact SVEC to Inspect
- 10) Back fill 1' of dirt
- 11) Install Red marking tape (Provided by SVEC)
Note: Install Phone / CATV wire
- 12) Finish covering ditch
- 13) Leave 30' Sch 80 PVC Conduit at pole for SVEC to install

