

Underground Service Layout

Scale: NTS Date: 7/21/09



Notes

- 1) Have SVEC spot Locations
- 2) Call TN One Call (1-800-351-1111)
- 3) Dig or Trench ditch to noted depth
Note: If less than the noted depth contact SVEC
- 4) Sch 80 PVC Required when under any Roads and Driveways
- 5) SVEC only allows 2 elbows in the ditch, 1 at the house and 1 at the pole
- 6) Install conduit
- 7) Install 1/4" Nylon Pull Rope in Conduit
- 8) Contact SVEC to Inspect
- 9) Back fill 1' of dirt
- 10) Install Phone / CATV wire 1' above Conduit
- 11) Finish covering ditch
- 12) Leave 30' PVC Sch 80 and Weatherhead at pole for SVEC to install

